

SS3011

SS 3011

Space Technology and Applications

• Midterm Exam

**Due Monday, November 19
Start of Class**

Take Home, Open Notes, Open Book, Open Web

Students Work Individually


Show All Work and Units on Every Calculation

Naval Postgraduate School
Monterey, California

SS3011

Iridium Constellation

First Global Satellite Network for Telecommunication.




- Orbit *Altitude*, 780 km**
- Orbit inclination, 86.4°**
- Orbit eccentricity, 0.0**
- Weight, 689 kg**
- Expected Lifetime**
(per satellite) 7-9 years

Naval Postgraduate School
Monterey, California

SS3011

**OK, each satellite costs over 80
Million ... and 7-9 years isn't
very many Phone Calls**



**.... so we want to design a "rescue mission" that
brings the satellite back to the Space Station ...
so it can be returned by the Shuttle for
refurbishment**

.... Shuttle usually returns empty anyhow

Naval Postgraduate School
Monterey, California

SS3011

Please Note

- This Mission *May* or
May NOT Be Feasible**


... you have to decide

Naval Postgraduate School
Monterey, California

SS3011

The "Rescue Ship"

- **Modified version of the 'Interim Control Module'**
(Designed as a backup for the Russian Zarya Module)



Russian Zarya Propulsion Module

ICM V2.1

Naval Postgraduate School
Monterey, California

SS3011

Rescue Ship (cont'd)


- **Serviced and Launched from International Space Station (ISS)**

- **ISS Orbit parameters**

Altitude, 407 km
Inclination, 51.6°
Eccentricity, 0.0

- **ICM Characteristics**

Propellant MMH (Monomethyl Hydrazine)
Isp -- 325 sec (upgraded engine)
Dry Weight, 8,600 kg




Naval Postgraduate School
Monterey, California

The Design Process

1) Design the Hohmann Transfer Orbit required to move the ICM from the ISS to the Iridium Orbit Altitude

i.e. ... calculate a_T , e_T for the transfer orbit



... assume $R_{\text{earth}} = 6371 \text{ km}$

Hint 1: R_{min} ... transfer orbit ...
= Radius ... ISS Orbit ...

Naval Postgraduate School
Monterey, California

Time of Flight

2) How Long Does it take the ICM to reach the Iridium orbit

• Hint 2: Kepler's Third law

$$T_T \Rightarrow \frac{2 \pi [a_{\text{Transfer}}]^{3/2}}{\sqrt{\mu}}$$

$$(\text{TOF})_T = \frac{T_T}{2}$$

Naval Postgraduate School
Monterey, California

Enter Transfer Orbit

3) Compute ΔV_1 Required to
Insert ICM into Transfer Orbit

• Hint 3:

$$\frac{\Delta V_1}{\sqrt{\frac{\mu}{R_{c_1}}}} = \sqrt{2 \left[1 - \frac{1}{\left[\frac{R_{c_2}}{R_{c_1}} + 1 \right]} \right]} - 1$$

Naval Postgraduate School
Monterey, California

Enter Iridium Orbit

4) Compute ΔV_2 Required to
Insert ICM into a Circular orbit
at the altitude of the Iridium Orbit

• Hint 4:


$$\frac{\Delta V_2}{\sqrt{\frac{\mu}{R_{c_1}}}} = \left[\sqrt{\frac{1}{\frac{R_{c_2}}{R_{c_1}}}} - \sqrt{2 \left[\frac{1}{\left[\frac{R_{c_2}}{R_{c_1}} \right]} - \frac{1}{\left[\frac{R_{c_2}}{R_{c_1}} + 1 \right]} \right]} \right]$$

Naval Postgraduate School
Monterey, California

SS3011

Change Orbital Planes

- 5) Once inserted into the orbital altitude of the Iridium
Calculate ΔV required for ICM to Perform a *simple plane change* to move from the orbital plane of the ISS to Iridium Orbital plane



• Hint 5

$$|\Delta V|_{\text{simple plane change}} = 2 \sin \left[\frac{\Delta i}{2} \right] V_{\text{initial}}$$


Naval Postgraduate School
Monterey, California

SS3011

Combined Plane Change

- 6) Compute the DV required to
Do the Iridium Orbit insertion and Plane
Change at the same time

Compare the results to performing the
maneuvers separately



Hint 6:

$$|\Delta V|_{\text{combined}} = \sqrt{|V_2|^2 + |V_1|^2 - 2|V_2||V_1|\cos[\Delta i]}$$

V_2 = Iridium orbit speed


V_1 = Velocity at perigee of transfer orbit

Naval Postgraduate School
Monterey, California

SS3011

The Return Trip

7) Design the Hohmann Transfer Orbit and ΔV 's required to return the ICM from the ISS to the Iridium Orbit Altitude



Hint 7:
Return trip is the reverse
of the Outward Bound trip

excepts rocket burns (ΔV 's)
are *retrograde* (i.e. opposite
direction from outward trip)

(Include Plane Change in
Calculations,
use minimum value)

Naval Postgraduate School
Monterey, California

SS3011

Fuel Budgeting

- Calculate the minimum amounts of fuel to be consumed for each burn and the minimum total fuel which must be budgeted for the round trip
- **Hint 8:** Start with the final burn and work backward
Don't forget that Both vehicles are making return trip

$$M_{\text{propellant}} = [M_{\text{dry}} + M_{\text{payload}}] \left[e^{\left[\frac{\Delta V_{\text{burn}}}{g_0 I_{sp}} \right]} - 1 \right]$$

Naval Postgraduate School
Monterey, California